



TANKLESS GAS REPLACEMENT PARTS LIST

EVERHOT® IGE 199 (C,R)(5,10) Models




Meets all LoNox and (SCAQMD)
South Coast Air Quality
Management District
Requirements

Effective: April 16, 2004
ECO 6828

**NOTE: BOTH MODEL AND SERIAL
NUMBERS ARE REQUIRED FOR
ORDERING REPLACEMENT
PARTS**

Dimensions and specification subject to
change without notice.



Parts Common to IGE-199(C,R)-(5,10)(N,X)

Reference Number and Description	Part Number
003 Wall Installation Bracket	239-44779-00
004 Connection Reinforcement Panel	239-44780-00
005 Heat Protection Plate	239-44781-00
006 Rubber Bushing	239-44782-00
007 Front Panel Packing	239-44783-00
008 Front Panel Packing Side	239-44784-00
009 Front Plastic Panel	239-44831-00
011 Rubber Bushing	239-44785-00
801 Screw	239-44837-00
802 Washer	239-44887-00
806 Screw	239-44891-00
807 Screw	239-44892-00
808 Screw	239-44893-00
809 Screw	239-44894-00

Parts Unique to IGE-199R-10(N,X)

Reference Number and Description	Part Number
001 Front Panel Assembly (U245-1110)	239-44769-00
002 Casing Assembly (U245-1100)	239-44775-00
- Main Controller (MC-45-4US-BW)	239-44509-00*

Parts Unique to IGE-199C-5 (N,X)

Reference Number and Description	Part Number
001 Front Panel Assembly (U245-1110-2)	239-44770-00
002 Casing Assembly (U245-1100-2)	239-44776-00
- Main Controller (MCC-45-4US-BW)	239-44510-00*

Water Heater Accessories

- Bathroom Remote Control (BC-45-4US-BW) (IGE-199R Models Only)	239-44507-00*
- 2nd Bathroom Remote Control Kit (BSC-45-4US-BW) (IGE-199R Models Only)	239-44508-00*
- Manifold Elect. Controls Pack A	239-44511-00*
- Manifold Elect. Controls Pack B	239-44512-00*
- Recess Box Enclosure (IGE-199R Models only)	239-44515-00*
- Pipe Cover Enclosure (IGE-199R Models Only)	239-44513-00*
- Pipe Cover Enclosure (IGE-199C Models Only)	239-44514-00*
- Plumbing Installation Kit, Copper	239-45003-00
- Plumbing Installation Kit, Iron	239-44961-00

* Denotes Service Stock Component.

Parts Common to IGE-199(C,R)-(5,10)(N,X)

Reference Number and Description	Part Number
103 Burner Unit Assembly	239-44790-00
104 Burner Case Front	239-44791-00
105 Burner Case Bottom Panel	239-44792-00
106 Packing	239-44793-00
107 Lean and Rich Bunsen burner Assembly	239-44794-00
108 Burner Case Back Panel	239-44795-00
109 Damper	239-44798-00
111 Packing of Combustion Chamber	239-44802-00
112 Lower Packing of Combustion Chamber	239-44803-00
113 Screw	239-44804-00
115 Combustion Chamber Front Plate	239-44807-00
116 Electrode	239-44808-00
117 Flame Rod	239-44809-00
118 Electrode Packing	239-44810-00
119 Electrode Holder	239-44811-00
120 Upper Packing of Combustion Chamber	239-44812-00
122 Fan Casing Assembly	239-44813-00
123 Blower Motor	239-44818-00*
127 Fan Connecting Bracket	239-44821-00
128 Fan Connecting Packing	239-44822-00
132 Combustion Chamber Bracket	239-44827-00
136 Flue Outlet	239-44832-00
137 Flue Outlet Packing	239-44833-00
138 Flue Outlet Packing -6	239-44834-00
140 Heat Exchanger Complete Assembly-C (U245-1310-C-S)	239-44838-00
705 PCB Bracket	239-44857-00
706 Igniter	239-44858-00
707 High Tension Cord	239-44859-00
708 Electrode Sleeve	239-44860-00
709 Thermister	239-44861-00
710 Thermister Clip Large	239-44862-00
711 Thermal Fuse Clip	239-44864-00
716 Anti-Frost Heater Clip	239-44866-00
717 Anti Frost Heater Clip A	239-44867-00
718 Anti-Frost Heater Clip	239-44868-00
803 Screw	239-44888-00
810 O-ring	239-44897-00
812 O-ring	239-44899-00


Parts Unique to IGE-199(C,R)-(5,10)N (Natural Gas)

Reference Number and Description	Part Number
110 Manifold Assembly-C (Natural Gas) (U245-200-C-AS)	239-44801-00

Parts Unique to IGE-199(C,R)-(5,10)X (LP Gas)

Reference Number and Description	Part Number
110 Manifold Assembly-A (LP Gas) (U245-200-A-AS)	239-44799-00


* Denotes Service Stock Component.



Parts Common to IGE-199(C,R)-(5,10)(N,X)

Reference Number and Description	Part Number
012 Rubber Bushing	239-44786-00
100 Gas Control Assembly	239-44787-00*
101 Screw	239-44788-00
102 Gas Connection (3/4" NPT)	239-44789-00
400 Water Inlet (3/4" NPT)	239-44841-00
401 Water Flow Servo & Sensor Assembly	239-44842-00*
402 Rectifier	239-44843-00
403 By-pass Servo Assembly	239-44844-00
404 Stop Bracket	239-44845-00
405 Plug Band	239-44846-00
406 Water Filter Assembly	239-44847-00
407 Filter Plug	239-44848-00
408 Hot Water Outlet (3/4" NPT)	239-44849-00
409 Stop Bracket	239-44851-00
410 Plug Band Small	239-44852-00
411 Drain Valve	239-44853-00
702 PCB Cover-Side	239-44854-00
703 PCB Cover-Front	239-44855-00
704 Transformer Assembly	239-44856-00*
709 Thermister	239-44861-00
715 120V Valve Heater Assembly	239-44865-00
730 PCB	239-44877-00*
731 Surge Protector	239-44879-00*
804 Screw	239-44889-00
805 Screw	239-44890-00
810 O-ring	239-44897-00
813 O-ring	239-44900-00
814 O-ring	239-44901-00
815 O-ring	239-44902-00
816 O-ring	239-44903-00
817 O-ring	239-44904-00
818 Packing	239-44905-00

* Denotes Service Stock Component.



Parts Common to IGE-199(C,R)-(5,10)(N,X)

Reference Number and Description	Part Number
715 120V Valve Heater Assembly	239-44865-00
720 Power Supply Harness	239-44870-00
721 Fuse Harness	239-44871-00
722 100V Harness	239-44872-00
723 Solenoid Valve Harness	239-44873-00
725 Thermal Fuse Harness	239-44874-00*
726 Mold-Type Over Heat Switch	239-44876-00
732 Frost Sensing Switch	239-44881-00
733 120V Anti-Frost Heater Assembly	239-44883-00
734 Sensor Harness-2	239-44885-00

* Denotes Service Stock Component.

[illegible]

[illegible]



Ambler, PA

For U.S. and Canada field service,
contact your professional installing plumbing contractor
or local Bradford White representative.

Sales/800-538-2020
800-532-4020

Fax/215-641-1670

Technical Support/800-334-3393
Fax/269-795-1089

Warranty/800-531-2111
Fax/269-795-1089

International:
Telephone/215-641-9400
Telefax/215-641-9750

Fax on Demand:
888-538-7833



Sales/866-690-0961
905-238-0100

Fax/905-238-0105

Technical Support/800-334-3393

Email

parts@bradfordwhite.com
techserv@bradfordwhite.com

www.bradfordwhite.com
www.bradfordwhitecanada.com