

Uponor

RADIANT HEATING,
PLUMBING AND FIRE
PROTECTION SYSTEMS

TUBE UNCOILER

TECHNICAL BULLETIN



Application

The Tube Uncoiler provides a steady base for Uponor PEX coils allowing for fast, easy installations. Its hold-down arm design keeps tubing in place while a swivel eyelet guides tubing for smooth, tangle-free uncoiling.

Included

- One support base
- One center-arm hub
- Four PEX tubing retainers
- Two vertical support rods

Part Number

E6061000

Assembly

1. Stand uncoiler upright by folding four base legs. Unfold the four tubing supports.
2. Unfold eyelet guide and snap into place.
3. Move the pin on the eyelet guide to the holes drilled in the eyelet hinge. This will lock the eyelet guide in place.
4. Create a basket by attaching four PEX retainers into the outside support holes.
5. Place the two vertical rods into the holes on either side of center

vertical rod. Place the coil of PEX tubing onto the uncoiler.

6. Slide the center-arm hub onto the center vertical rod. Insert four arm pieces into center hub.
7. Place second coil of tubing over arms.
8. Feed end of PEX tubing from bottom coil through eyelet guide.

Note: Move the guide pin on the swivel guide arm to keep it in place (see step 3). Placing a second coil of tubing over the arms provides an even sturdier base. Refer to the following instructions to properly place a second coil of tubing over the arms.

Placing a Second Coil of Tubing

1. Remove the arms from the center hub.
2. Slide the hub up.
3. Reinsert the arms into the hub on top of the coil.
4. Place another coil on top of the arms. This creates a fast, easy transition between coils (see step 7).

Storage

The Tube Uncoiler folds up into a compact 6" x 6" x 4' space for easy storage. The collapsible four-legged base is easy to assemble and provides sturdy positioning.

Tubing Guide


The 360-degree swivel arms act as a tubing guide.

Hardware

No additional hardware or tools are required for setup.

Tubing Size

The Tube Uncoiler accommodates up to 1" Uponor PEX tubing.



Tube Uncoiler Components

Uponor, Inc.

5925 148th Street West
Apple Valley, MN 55124
Tel: (800) 321-4739
Fax: (952) 891-1409

Web: www.uponor-usa.com

E-mail: learnmore@uponor-usa.com

Uponor Ltd.

655 Park Street
Regina, SK S4N 5N1
Tel: (888) 994-7726
Fax: (800) 638-9517

Web: www.uponor.ca

E-mail: info@uponor.ca