




**Fig. 2: Prestige Jacket Components**

| Item | Part No. | Description                              |
|------|----------|------------------------------------------|
| 1    | PSCS01   | Display/Control Panel                    |
| 2    | PSJKT01B | Base Panel - Solo 110                    |
|      | PSJKT02B | Base Panel - Solo 175/250                |
| 3    | PSJKT01F | Front Jacket Panel                       |
| 4    | PSJKT01R | Rear Jacket Panel - Solo 110             |
|      | PSJKT02R | Rear Jacket Panel - Solo 175/250         |
| 5    | PSJKT01S | Side Jacket Panel (Left and Right)       |
| 6    | PSJKT01T | Top Jacket Panel - Solo 110              |
|      | PSJKT03T | Top Jacket Panel - Solo 175/250          |
| 7    | PSJKT02T | Top Jacket Panel - Access - Solo 110     |
|      | PSJKT04T | Top Jacket Panel - Access - Solo 175/250 |
| 8    | PSJKT03  | Control Cover Panel                      |
| 9    | PSRKT21  | Wall Mounting Bracket with Hardware      |