




PARTS AND SERVICE DEPARTMENT
Nashville, Tennessee
615-889-8900 • Fax: 615-547-1000
www.Lochinvar.com


Replacement Parts List

**Solar Indirect
Tanks
SDT-SET-SIT**




SOLAR INDIRECT (SIT)

SOLAR DUAL COIL (SDT)



SOLAR ELECTRIC COIL (SET)



ITEM	PART NUMBERS	DESCRIPTION	MODEL NUMBER
1	JKT30004	JACKET TOP	SET065, 080
1	JKT30005	JACKET TOP	SET119
1	JKT20007	JACKET TOP	SDT065, 080 / SIT065, 080
1	JKT20011	JACKET TOP	SDT119 / SIT119
1	JKT20002	JACKET TOP	SIT030, 040
1	JKT20024	JACKET TOP	SIT050
2	MSC20087	CAP, HOLE 3.25 OD X 1.29 ID	ALL
3	MSC20088	CAP, HOLE 3.25 OD X 1.89 ID	ALL
4	MSC20089	CAP, HOLE 3.25 OD X 1.16 ID	ALL
5	MSC20120	DOME PLUG, 2" DIAMETER	ALL
6	RLV1001	T & P RELIEF VALVE	SIT030, 040, 050
6	RLV1006	T & P RELIEF VALVE	ALL SET & SDT / SIT065, 080, 119
7	TST1067	THERMOSTAT	ALL SET
8	TST20018	THERMOSTAT BRACKET	ALL SET
9	ELE1417	ELEMENT	ALL SET
10	GKT2513	ELEMENT GASKET	ALL SET
11	JKT60108	JUNCTION COVER, LEFT	ALL SET
12	JKT60109	JUNCTION COVER, RIGHT	ALL SET
13	MSC20090	CAP, ELEMENT	ALL SET
14	TST20015	THERMOSTAT SENSOR	ALL SDT & SIT

Please provide model & serial number when ordering parts.

Notes