



**F145RF-1600  
Wireless Remote Sensor**

**WIRELESS REMOTE SENSORS FOR WIRELESS  
THERMOSTAT SYSTEM**

Wireless Indoor and Outdoor Sensors for use with 1F98EZ-1621 Emerson Blue Wireless Easy Install Thermostat System.

**FEATURES**

- One remote sensor is configurable for indoor or outdoor use.
- Perfect for securing the interface in one area or room while sensing temperature in the conditioned space.
- Up to 3 indoor and 1 outdoor wireless remote sensors can be used on one 1F98EZ-1621 wireless thermostat system

**SPECIFICATIONS**

Operating Range (based on interface range)  
 Operating Ambient . . . . . -4° to 129°F (-20° to 54°C)  
 Operating Humidity Range . . . . . 0 to 90% RH (non-condensing)  
 Maximum Distance from Interface . . . . . 300'

**TECHNICAL HELP**

Installation and Troubleshooting: 37-7247

**WIRELESS REMOTE SENSOR**

| Model Number | Color         | Dimensions               | Application   |
|--------------|---------------|--------------------------|---|
| F145RF-1600  | Classic White | 4 1/2" x 3 1/4" x 1 1/2" | Compatible with Emerson Blue Wireless Easy Install Thermostat System. |